

ATTENZIONE: LEGGERE PER UN CORRETTO USO

AVVERTENZE! il montaggio del prodotto deve essere eseguito solo da adulti. Leggere e conservare per future referenze. **ATTENZIONE!** Non adatto a bambini di età superiore a 36 mesi. Portata massima 25 Kg. Resistenza meccanica non sufficiente oltre i 25 Kg. Articolo indicato per bambini a partire dai 12 mesi. Non lasciare i bambini incustoditi. Si raccomanda agli adulti la supervisione del bambino durante l'utilizzo. Non utilizzare il prodotto sulle strade, su percorsi in discesa, vicino a scale, piscine o depositi d'acqua in quanto si potrebbero generare rischi di lesione all'utente o a terze parti. Utilizzare in casa o in aree gioco sicure, piane e protette. Usare il gioco in aree ben illuminate. Mai usare al buio. Il bambino deve sempre usare le scarpe nell'utilizzo del veicolo. Quando il veicolo è operativo fare attenzione affinché i bambini non mettano mani, piedi o altre parti del corpo, indumenti o altre cose, vicino alle parti in movimento. Non fare spingere il cavalcabile ad un bambino se un altro bambino vi è seduto sopra. Non utilizzare in caso di parti rotte o danneggiate o se le ruote mostrano segni di usura eccessiva. Se presente il cestino o il rimorchio non deve essere caricato di pesi eccessivi. Parcheggiare il veicolo al riparo dagli agenti atmosferici.

Per i genitori: istruire i bambini sull'utilizzo e sulle principali norme di sicurezza prima dell'uso. Il giocattolo deve essere utilizzato con cautela per evitare cadute e collisioni con conseguenti lesioni all'utente o a terzi. E' responsabilità dei genitori controllare tutte le parti del giocattolo prima dell'uso. Assicurarsi che il giocattolo sia sicuro prima della guida. Non usare benzene o sostanze infiammabili vicino al veicolo. Gli attrezzi per il montaggio e il materiale di imballaggio non fanno parte dell'articolo e devono essere eliminati prima di dare il gioco al bambino. Gli adesivi devono essere applicati da un adulto. Colori e modelli possono variare rispetto alle foto. Istruzioni per il lavaggio: pulire il prodotto con un panno umido. Non usare detergenti abrasivi.

ATTENZIONE! Tenere lontano dal fuoco.



A brand of BCS Srl

IMPORTATO DA: **BCS Srl**

Via I° Maggio, 5/G - 40057 Quarto Inferiore

Bologna (ITALY) - www.bcsgiochi.com

+ 39 051 767392 - bcs@bcsgiochi.com

MADE IN CHINA

Leggere e conservare per futura referenza


12/36
mesi



SPRING

ART. 1499

MANUALE D'ISTRUZIONI



PARTICOLARI DA ASSEMBLARE PRESENTI NELLA SCATOLA

Controllare tutti i particolari, assicurarsi che ciascun particolare non sia rotto o mancante.

- | | |
|----------------------|-----------------------------|
| A. Cestino | G. Telaio |
| B. Sedile | H. Maniglia |
| C. Parabrezza | I. Ruota anteriore |
| D. Ruote posteriori | J. Bracciolo di protezione |
| E. Assale posteriore | K. Appoggipiedi |
| F. Asta in metallo | L. Borchie ruote posteriori |




ASSEMBLAGGIO


Attenzione:

Per la sicurezza del bambino questo prodotto deve essere assemblato da un adulto.


NOTA: Viti e dadi sono già collegati alle parti interessate



1. Inserire lo spartigambe tra sedile e telaio, fissare con viti e dadi.




2. Inserire l'assale posteriore nel tubo del telaio, quindi inserire le ruote fino in fondo (click sonoro)




3. A: Fissare il parabrezza al manubrio dall'alto verso il basso.

B: Avvitare le due parti tra loro.


C: Coprire il pannello.




4. Inserire la parte anteriore del telaio nell'alloggio corrispondente alla forcella. Bloccare con il perno spingendolo fino in fondo.




5. Mettere in posizione l'asse direzionale (tra A e B) e bloccare con il dado.




6. Inserire il tubo di guida nel suo corrispondente. Regolare l'altezza facendolo scorrere. Bloccarlo con la vite in alto o in basso.



7. Premere con forza il cestino contro il telaio. Bloccarlo con la vite e con il dado.



8. Infilare lo sparti-gambe nella protezione centrale ed inserirla nei corrispondenti innesti fino al bloccaggio.



9. Inserire l'appoggipiedi nel telaio fino al blocco.

WARNING: READ FOR A CORRECT USE

WARNINGS: mounting of the product should be performed only by adults. Read and keep for future reference. WARNING! Not suitable for children over the age of 36 months. Maximum flow Insufficient mechanical strength 25 Kg over 25 Kg Item suitable for children from 12 months. Do not leave children unattended. It is recommended that adult supervision of children during use. Do not use the product on the roads, paths of descent, near stairs, swimming pools or deposits of water as this could create risks of injury to you or third parties. Use at home or in play areas safe, flat and protected. Use the game in well-lit areas. Never use the the dark. The child should always use the shoes in the use of the vehicle. When the vehicle isoperating take care that children do not put hands, feet or other body parts, clothing or other things close to moving parts. Do not push the ride-on to a child if another child is sitting on it. Do not use in case of broken parts or damaged or if the wheels show signs of excessive wear. If there is a trash or trailer must be loaded with weights excessive. Park the vehicle away from the elements.

For parents: the use and educate children on key safety standards prior to use. The toy must be used with caution to avoid falls or collisions causing injury user or to third parties. And the parents' responsibility to check all parts of the toy before use. Make sure the toy is safe before driving. Do not use benzene or flammable substances near the vehicle. The tools for assembly and packing materials are not part of the article and must be removed before giving the game to the child. The stickers must be applied by an adult. Colors and patterns may vary from photos. Washing instructions: clean the product with a damp cloth. Do not use abrasive cleaners.

WARNING! Keep away from fire.

SPRING

ART. 1499

INSTRUCTION MANUAL




IMPORTED FROM: **BCS Srl**
Via I° Maggio, 5/G - 40057 Quarto Inferiore
Bologna (ITALY) - www.bcsgiochi.com
+ 39 051 767392 - bcs@bcsgiochi.com

MADE IN CHINA

Read and keep for future reference



12/36
mesi



Assembling parts in the package

Check the all parts, and make sure every part has no broken and missing.


- A: Basket
- B: Saddle set
- C: shield sets
- D: Rear wheel
- E: Rear wheel axle
- F: Connecting string
- G: Frame
- H: Handlebar
- I: Front wheel set
- J: Safety bumper
- K: Footrest
- L: Rear wheel cover




INSTALL

Warning: in order to protect your baby safe, the tricycles must be assembled by the adults.


NOTE: The screws and nuts for installing have moored to the relevant parts.




1. Insert the armrest between the seat and frame, fixed with screws and nuts.




2. Insert the rear wheels axle into the axle's linking tube, and then insert the axle into the hole of wheels




5. Put the adjusting axle through the A and B, lock them with nut.




6. Insert the pushing handlebar into the adjusting tube (down) and tight it with screw.
Adjusting the height of the handlebar: release the screw, move it upward or downward till the right place and then tight the screw.




7. Push the basket hardly, get it stuck on the iron tube of the end of the main frame, then lock it with screw and put.




8. Insert the armrest into the armrest till it locked. Fix the safety belt on the safety protector.



9. Insert the footrest into the main frame till it locked.



3. A: Put the front shield sets onto front wheel sets from upside to downside
B: Screw up the front shield sets with the front wheel sets.
C: Put on the cover on the metal panel properly



4. Insert the front main frame into the front fork, then lock them with the clip, pushing it till the end.